

Description: Polyether Block Amide, 20% Barium Sulfate

The Polyether-block amide grades offered by Arkema (PEBAX) and Evonik (Vestamid Care ME) are a plasticizer-free thermoplastic elastomer that is ideally suited for medical grade tubing and film due to its ease of processing and wide range of properties. Barium sulfate is a white powder that occurs naturally as barite or in the synthetic form Blanc Fixe. It has a density of (4.5 g/cm³) and offers radiopacity. Barium sulfate is the most widely used radiopacifier in the medical device industry because of its ease of processing, excellent dispersibility, color stability, and low-cost.

Form	Pellets
Appearance	White, Opaque
Processing Method	Injection Molding or Extrusion

Typical Material Properties: Pebax SA01 MED, 20% BaSO₄

Material Property	Test Method	Units	PBX 7220	PBX 7020	PBX 6320	PBX 5520	PBX 4520	PBX 4020	PBX 3520	PBX 2520
Durometer (instantaneous)	ASTM D2240	Shore D	74	71	66	57	47	45	34	28
Density	ASTM D792	g/cm ³	1.2	1.19	1.2	1.21	1.21	1.2	1.2	1.19
Melt Flow (230C, 2.16 kg)	ASTM D1238	g/10 min	16.8	16.5	17.8	46.7	54.3	38.7	58.8	62.1
Tensile Stress at Yield	ASTM D638	MPa	36.1	30.1	21.6	23.6	8.81	N/A	N/A	N/A
Tensile Stress at Break	ASTM D638	MPa	40.7	40.3	35.8	23.6	13.6	18.5	8.3	5.66
Elongation at Break	ASTM D638	%	270	360	460	>500	>500	450	>500	>500
Flexural Modulus	ASTM D790	MPa	740	640	370	228	110	105	31	16.2
Flexural Stress	ASTM D790	MPa	27.5	22.7	15.2	9.1	5.08	4.65	1.53	0.98

Typical Material Properties: Vestamid Care ME, 20% BaSO₄

Material Property	Test Method	Units	VCME 7120	VCME 6220	VCME 5520	VCME 4720	VCME 4020
Durometer (instantaneous)	ASTM D2240	Shore D	76	65	59	51	48
Density	ASTM D792	g/cm ³	1.21	1.2	1.18	1.19	1.21
Tensile Stress at Yield	ASTM D638	MPa	36.7	24.1	23.0	15.6	12.0
Tensile Stress at Break	ASTM D638	MPa	36.7	29.3	25.3	20.4	16.8
Elongation at Break	ASTM D638	%	150	210	300	470	>500
Flexural Modulus	ASTM D790	MPa	1020	430	260	130	87
Flexural Stress	ASTM D790	MPa	38.5	17	10.8	6.18	4.25

Drying Requirements

PEBARO grades are hygroscopic and do require drying prior to processing. It is recommended to dry all PEBARO grades to <0.05% moisture using a desiccant dryer at the following temperatures:

- 140 F - PBX2520, PBX3520, PBX4020, VCME4020, VCME4720
- 160 F - PBX4520, PBX5520, PBX6220, PBX7020, PBX7220, VCME5520, VCME6220, VCME7120

Purging

A similar durometer Polyether block Amide is recommended for purging into or out of PEBARO grades.

Handling

Supplied as free-flowing pellets. The Safety Data Sheet should be consulted for other detailed guidelines.

Storage

Typical shelf life is two years from date of delivery in unopened packaging. When not being used, the container and liner should be closed and stored in a cool, dry area protected from UV exposure.

Processing

For processing recommendations please contact your CS sales representative.

Disclaimer: Compounding Solutions strictly prohibits the use of any PEBARO resins in applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days. Unless Compounding Solutions otherwise expressly agrees by written contract, the Compounding Solutions trademarks and the Compounding Solutions name shall not be used in conjunction with customers' medical devices, including without limitation, permanent or temporary implantable devices, and customers shall not represent to anyone else, that Compounding Solutions allows, endorses or permits the use of Compounding Solutions products in such medical devices. Further, all implantable medical devices, whether permanent or temporary, carry a risk of adverse consequences. With regard to implantable medical devices, you should not rely upon the judgment of Compounding Solutions. Any decision regarding the appropriateness of a particular medical device in a particular medical application or for a specific clinical use should be based upon the judgment of your physician, medical device supplier and the United States Food & Drug Administration and/or the European process of Medical Device notification. Unless otherwise specifically stated by Compounding Solutions in writing, Compounding Solutions does not perform clinical medical studies on implantable medical devices. Compounding Solutions cannot weigh the benefits against the risks of a device and does not offer a medical judgement on the safety or efficacy of use of any Compounding Solutions product in a medical device. The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, COMPOUNDING SOLUTIONS expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.

See Safety Data Sheet for Health & Safety Consideration